




Recreational & Athletic Flooring Installation Instructions



Your complete guide to
installing:

- ◆ Flip-It
- ◆ Hid-N-Lok
- ◆ Hid-N-Lok II
- ◆ Aerobic Tile
- ◆ Pro-Lok
- ◆ Dec-O-Lok

RECREATIONAL & ATHLETIC FLOORING INSTALLATION INSTRUCTIONS

Pawling Rubber Floor Tiles

Flip-It™, Hid-N-Lok™, Hid-N-Lok II™, Aerobic Tiles™, Pro-Lok™, Dec-O-Lok™

Installation Tools/Equipment

- | | |
|-----------------------|---------------------------------------|
| -Utility Knife | -3' Straight Edge |
| -Supply of Blades | -50 lb. Carpet Roller |
| -Chalk Line | -Framing Square |
| -Rigid Measuring Tape | -Protractor (arcs/columns) |
| -Rubber Mallet | -Template Material (e.g. Kraft paper) |
| -Pencil | -30" x 30" x 1/4" Masonite |

Preparation of Floor

Tiles may be installed over any relatively smooth, hard surface. This includes on or below grade concrete, hardwood, plywood, stone, VCT, or ceramic tile. The floor should be free of protruding objects, deep recessions, or indentations.

Floor should be clean, dry, and level. Remove dust, debris, moisture, and powder accumulations from all surfaces prior to installing rubber flooring.

Note: Tiles may not be installed over carpeting of any grade.

Preparation of Tiles

Allow tiles to come to room temperature prior to installation.

Room Dimensions/Layout of Tiles

- ◆ Measure room accurately in both directions.
- ◆ Determine required width of cut tiles around perimeter of room. Take into account the following factors in determining the layout of your tiles:
 - “Cut tiles” around perimeter of room should be no less than 2” wide. While it is preferred that cut pieces on opposite sides of the room be of *generally* equal dimensions, it is more important that no tiles be cut to less than 2” in order to allow the interlocks to properly connect.
 - Factor in any jogs/walls, which will affect the layout of the tiles. It is important that the layout be adjusted to prevent cut pieces of less than 2” at both the jogs and outer walls.
- ◆ Starting at one corner of the room, snap a chalk line indicating the placement of the edge of the outermost course of full (uncut) tiles.
- ◆ Snap a 2nd chalk line perpendicular to the first, indicating the edge of the course of full (uncut) tiles on the adjacent wall. Use a carpenter's square to make certain that chalk lines are square at intersection.

RECREATIONAL & ATHLETIC FLOORING INSTALLATION INSTRUCTIONS

Laying Tiles

- ◆ Lay first full tile flush to intersection of chalk lines. Interlock tiles into place, making certain to complete each full row, and ending with the last full (uncut) tile, before beginning next row.

*Note: When installing **Hid-N-Lok™**, **Hid-N-Lok II™**, **Aerobic Tile-Traction Top™** and **Dec-O-Loc™**, be certain to lay out initial course of tiles **with both open tabs facing out**. This will prevent the installer from having to "lift" tiles to interlock into place.*

*When installing **Flip-It™**, note that tiles have a thin "flashing" on the inside edge of the interlocking tabs. Be certain to install these reversible tiles **flashing side down** for a uniform fit and appearance.*

- ◆ Lay out all full tiles in the above fashion. Be certain to complete one full row at a time, checking periodically to make certain rows are square.

Note: Do not install tiles simultaneously in two directions.

Cutting Tiles

When all full tiles are completely in place, go back to cut in the perimeter tiles.

Measure distance from wall to outside edges of full tiles, allowing for a ¼" gap at wall, and mark these dimensions on tile to be cut.

Note: It is helpful to cut tiles on a smooth hard surface, such as a 30" x 30" sheet of ¼" Masonite. Tiles may be cut top side up, using a 3' straight edge and utility knife.

Install cut tiles into place, and continue in the same manner around perimeter of room.

Completion

When all tiles are completely installed, tiles may be "rolled" into place using a 50 lb. – 100 lb. carpet roller to secure interlocks.